




Note: The $\phi 30$ holes are for access, we recommend using M10 anchor bolts that will fit into the $\phi 16$ holes.