
ASLHDSBxx Floor Stand Assembly Guide




Safety Instructions


- · Installation drawings and accessories shall be subject to receipt.
- · This Installation guide is for reference only.
- · To ensure a secure installation, be sure to firmly tighten the screws.
- · To ensure your safety, please adhere to the specified size and weight limits when using it.
- · Ensure installation and assembly is done on a flat surface.
- · Load-bearing range: 30kg
- · Applicable to: 43" 55" ONLY

Assembly Instructions


1. Creating the Side Rails



Step 1-2 Side Rail Support Assembly Screw one the of the side rail supports through the hoist hole on the side of the side rail using two of the M6 x 10mm screws. For the other side, screw two of the M6 x 10mm screws directly into the side rail support ensuring there is a gap between the bottom of the screw head and the surface of the side rail support for hanging in the hoist hole. Carefully insert the side rail support in the hoist hole making sure both screws are inside the hoist hole. Repeat this for the other side rail.



Using Five M6 x 10mm Screws, screw the side rail base support to the side rail. Repeat this for the other side rail. Side Rail Base Support M6 x 10mm Hex Socket Head Screws (×5) The sides of the floor stand are now assembled.



2. Completing the floor stand

